

Gel Toothpaste - "Sparkling Silver Blue"

Oral Care

Ref: OC0395

Product Name	INCI Name	%WW	Supplier
A			
		100.00	
Pricerine 9090	Glycerin	8.30	www.croda.com
Blanose Cellulose Gum 9M31F	Cellulose Gum	0.40	www.aqualon.com
Water	Aqua	11.40	-
Blue 1 (0.25% aqueous solution)	Blue 1 (CI 42090)	0.50	www.spectracolors.com
Sorbitol 70% Solution	Sorbitol	57.30	www.carldicke.com
Levenol C-201	Glycereth-17 Cocoate	2.00	www.kaochemicals-eu.com
B			
Renex PEG 1500	PEG-32	2.50	www.croda.com
Sodium Saccharin	Sodium Saccharin	0.20	www.alfa.com
Sodium Benzoate	Sodium Benzoate	0.30	www.alfa.com
Water	Aqua	4.20	-
C			
Tixosil 43	Hydrated Silica	12.50	www.rhodia-novecare.com
D			
Winter Kiss	Flavour	0.20	www.bell-europe.com
Prestige Sparkling Silver	Mica (and) Titanium Dioxide	0.20	www.sudarshan.com

Procedure

1. Mix phase A and stir until homogeneous
2. Mix phase B and add to phase A while stirring
3. Add phase C to phase AB and stir until homogeneous
4. Add phase D to phase ABC and stir until homogeneous
5. Fill into an appropriate container

Stability

Stable for at least 6 months at RT and 40°C.

Stable for 1 month at 50°C.

Sudarshan Chemical Industries Ltd.

Global Head Office:
162 Wellesley Road, Pune
411001, India
Tel : +91 20 260 58 888
Fax : +91 20 260 58 222
e-mail : cosmeticpigments@sudarshan.com

Sudarshan Europe BV

Crystal tower, 24th floor, Orlyplein 10,
PO Box 58176, 1040 HD, Amsterdam,
The Netherlands
Tel: +31 (0)20 475 2311
Fax: +31 (0)20 475 2312
e-mail: eu@sudarshan.com

Sudarshan North America Inc.

76 N. Walnut street,
Ridgewood NJ,
USA 07450.
Tel: +1 201 882 2135
Fax: +1 201 882 0157
e-mail: usa@sudarshan.com